# ALMANDO MASTERPLAY - INSTALLATION MANUAL (ENGLISH)

**IMPORTANT** You can connect **almando Masterplay** to only **ONE** Bang & Olufsen Link product! If you have multiple B&O link products, you have to resolve the common Masterlink wiring. Each B&O link product has to be operated with its own **almando Masterplay**.

**The almando Masterplay is compatible with these B&O link products: BeoLab 3500, BeoLab 2000, LCS 9000, BeoLink Passive, BeoLink Active**

**SETUP** **These steps must be done only once to getting started:**

1. Connect the B&O link product to the mains power supply.
2. Press the TIMER key on the Masterlink speaker or on the BeoLink IR eye. The TIMER LED lights up red.
3. Connect **the almando Masterplay** and the B&O link product with a Masterlink cable.
4. Connect the **almando Masterplay** to the mains power supply.
5. **IMPORTANT: Wait 20 seconds! (During this time, the registration is done)**
6. Connect the audio source to the **almando Masterplay** (e.g. B&O Playmaker, B&O BeoSound 5, Sonos Connect, Apple Airport Express).
7. Start the playback on the connected source.
8. **Now configure DIP-switch 2:**
   - DIP 2 ON (top) for sources with trigger voltage (Powerlink), e.g. Playmaker, BeoVision
   - DIP 2 OFF (bottom) for sources without trigger voltage, e.g. Sonos Connect, Apple Airport Express (operating mode: automatic signal detection)

(9.) If necessary configure DIP-switch 1 for the turn-off-delay: (only for operating mode automatic signal detection):
- DIP 1 ON (top) turn-off-delay ½ minute
- DIP 1 OFF (bottom) turn-off-delay 2 minutes

10. Configure your B&O link product to **option 6** in order to adjust the sound settings to your personal preference (**in particular, the maximum volume** for a pleasant volume control with your iPhone for example).
This can be stored permanently as the default setting.
**For Beolab 3500 / LCS 9000 we recommend: vol.60**
To do this, you need a B&O remote control (e.g. Beo4 or Beolink 1000).
The required key sequence will vary depending on the B&O remote control or type of B&O link product. Detailed information is available in your B&O manual.

11. **IMPORTANT:** Finally, configure your B&O link product to **option 0**.

**NOTE** **For the daily operation of your Bang & Olufsen link product you don't need the B&O remote control anymore. Just start the playback on the connected source and the B&O link product will be switched on automatically.**
**The volume can be controlled on the source itself (e.g. with the iPhone)**

# ALMANDO MASTERPLAY - INSTALLATIONSANLEITUNG (DEUTSCH)

**WICHTIG** An jedem **almando Masterplay** kann nur **EIN** Bang & Olufsen Linkprodukt angeschlossen werden!
Haben Sie mehrere Linkprodukte, so muss die gemeinsame Masterlink-Verkabelung aufgetrennt werden. Jedes Linkprodukt wird standalone mit jeweils einem eigenen **almando Masterplay** betrieben.

**Der almando Masterplay ist kompatibel zu folgenden B&O Linkprodukten: BeoLab 3500, BeoLab 2000, LCS 9000, BeoLink Passive, BeoLink Active**

**SETUP** **Diese Schritte zur Inbetriebnahme sind nur einmal durchzuführen:**

1. Das B&O Linkprodukt mit dem Stromnetz verbinden.

2. Die TIMER-Taste am Masterlink-Lautsprecher bzw. am BeoLink IR-Auge drücken. Nun sollte die TIMER-LED rot leuchten.

3. Den **almando Masterplay** und das B&O Linkprodukt mit einem Masterlink-Kabel verbinden.

4. Den **almando Masterplay** an das Stromnetz anschließen.

5. **WICHTIG: 20 Sekunden warten! (in dieser Zeit erfolgt die Anmeldung)**

6. **Erst jetzt** Zuspielgerät am **almando Masterplay** anschließen.
(z.B. B&O Playmaker, B&O BeoSound 5, Sonos Connect, Apple Airport Express)

7. Musikwiedergabe am Zuspielgerät starten

8. **DIP-Schalter 2 optionieren:**
- DIP 2 ON (oben) für Geräte mit Schaltspannung (Powerlink), z.B. Playmaker, BeoVision
- DIP 2 OFF (unten) für Geräte ohne Schaltspannung, z.B. Sonos Connect, Apple Airport Express (Betriebsart: automatische Signalerkennung)

(9.) ggf. DIP-Schalter 1 für die Dauer der Ausschaltverzögerung optionieren:
(nur nötig in der Betriebsart Signalerkennung - DIP-Schalter 2 OFF):
- DIP 1 ON (oben) Ausschaltverzögerung ½ Minute
- DIP 1 OFF (unten) Ausschaltverzögerung 2 Minuten

10. Konfigurieren Sie Ihr Linkprodukt auf **Option 6** und passen Sie die Klangeinstellungen Ihren persönlichen Hörgewohnheiten an (**insbesondere die maximale Lautstärke** für einen angenehmen Regelumfang z.B. am iPhone). Dies kann dann dauerhaft als Grundeinstellung gespeichert werden.
**Empfehlung bei Beolab 3500 / LCS 9000: Vol.60**
Hierzu benötigen Sie eine B&O Fernbedienung (z.B. Beo4 oder Beolink 1000). Die erforderliche Tastenfolge ist je nach Fernbedienung und Art des B&O Linkprodukts unterschiedlich.
Detaillierte Informationen finden Sie in Ihrer B&O Anleitung.

11. **WICHTIG:** Konfigurieren Sie abschließend Ihr B&O Linkprodukt auf **Option 0.**

**HINWEIS** **Für den täglichen Betrieb Ihres Bang & Olufsen Linkproduktes benötigen Sie die B&O Fernbedienung NICHT MEHR. Es genügt, die Wiedergabe am angeschlossenen Zuspielgerät zu starten und das Linkprodukt wird automatisch eingeschaltet. Die Lautstärkeregelung erfolgt dann am Zuspielgerät selbst, z.B. mit dem iPhone.**