



Recommended main room setups




Audio system in one room

Option programming BeoSound : Ready for use
 Factory setting BeoSound : Option 1



Video system in one room


Option programming BeoVision : Ready for use
 Factory setting BeoVision : Option 1



AV system in one room


1.
 Option programming BeoVision : Ready for use
 Factory setting BeoVision : Option 1

Option programming BeoSound : Ready for use
 Factory setting BeoSound : Option 1



2.
 Option programming BeoVision : Option 2
 Factory setting BeoVision : Option 1

Option programming BeoSound : Option 0
 Factory setting BeoSound : Option 1




AV system in two rooms

Option programming BeoVision : Option 2
 Factory setting BeoVision : Option 1

Option programming BeoSound : Option 2
 Factory setting BeoSound : Option 1


Recommended setups for one product in the link room



BeoLab 3500

Option programming
Factory setting


: Ready for use
: Option 6



BeoLab 2000

Option programming
Factory setting


: Ready for use
: Option 6



BeoVision MX 4002

Option programming
Factory setting


: Ready for use
: Option 6



BeoLink Active

Option programming
Factory setting

: Ready for use
: Option 6



BeoLink Passive

Option programming
Factory setting

: Ready for use
: Option 6