

Technical information

Software/Build info BeoVision 10-40 MK II/III

Information valid for: BeoVision 10 - 40 MK II, BeoVision 10 - 40 MK III

Last modified: 21-11-2013 13:43:01

MK III	MK II	The Build contains the below software versions							*DVB-HD		
Type 9553-54	Type 9572-73	Build	PW 328	FEP	System Module MK I	System Module MK II	DSM- FEP	DSM- DSP	✕	✕	#
Serial number	Serial number								DVB-HD T/C	DVB-HD T/C/S2	DVB-HD T2/C or T2/C/S2
-----	Service SW	229	4.68a	4.54a	20.06v	50.06d	5.27a	5.24a	0.1.9.9.0	0.1.9.9.0	0.1.9.9.0
23054228	Service SW	227	4.66a	4.54a	20.06v	50.06a	5.27a	5.24a	0.1.9.9.0	0.1.9.9.0	0.1.9.9.0
-----	Service SW	224	4.63a	4.53a	20.06v	50.06a	5.24a	5.21a	0.1.9.9.0	0.1.9.9.0	0.1.9.9.0
-----	Service SW	224	4.63a	4.53a	20.06v	50.06a	5.24a	5.21a	0.1.8.9.0	0.1.8.9.0	0.1.8.9.2
22679539	Service SW	224	4.63a	4.53a	20.06v	50.06a	5.24a	5.21a	0.1.8.9.0	0.1.8.9.0	0.1.8.9.0
22580995	Service SW	210	4.63a	4.53a	20.06v	50.06a	5.24a	5.21a	0.1.8.9.0	0.1.8.9.0	0.1.8.9.0
	22562345	210	4.40a	4.36c	20.06r	50.05n	5.18a	5.15a	0.1.7.1.0	0.1.7.1.0	0.1.7.2.0
	-----	166d	4.10d	4.04a	20.06o	50.05k	5.18a	5.15a	0.1.7.1.0	0.1.7.1.0	0.1.7.2.0
	22403934	166d	4.10d	4.04a	20.06o	50.05k	5.18a	5.15a	0.1.6.6.0	0.1.6.3.0	0.1.6.4.0
	Service SW	166	4.10a	4.04a	20.06m	50.05i	5.18a	5.15a	0.1.6.6.0	0.1.6.3.0	0.1.6.4.0
	22281589	166	4.10a	4.04a	20.06m	50.05i	5.18a	5.15a	0.1.6.5.0	0.1.6.3.0	-
	22253156	165	4.09c	4.04a	20.06m	Not sup.	5.18a	5.15a	0.1.4.7.0	0.1.4.5.0	Not sup.
	22164042	155	4.05e	4.03f	20.06f	Not sup.	5.18a	5.15a	0.1.4.7.0	0.1.4.5.0	Not sup.
	22119332	153	4.05b	4.03f	20.06f	Not sup.	5.18a	5.15a	0.1.4.7.0	0.1.4.5.0	Not sup.
	22013368	127	3.80e	3.80m	20.06a	Not sup.	5.16a	5.15a	0.1.4.7.0	0.1.4.5.0	Not sup.
	21936149	109e	3.36f	3.14c	20.05r	Not sup.	4.23a	4.19a	0.1.4.5.0	-	Not sup.

Note: A few products may be outside the serial number series!

*Optional accessory

✕ DVB-HD T/C and T/C/S2 software version 0.1.4.5.0 or higher is tested OK from Build 109e.

DVB-HD T2/C and T2/C/S2 software version 0.1.6.4.0 or higher is tested OK from Build 166.

When replacing modules and making software updates it is important that all software versions in a Build match!